



Instructions for Portable Pro Lift Drive-Up Ramps (RR-PPL)

Made in the USA

General Guidelines

- It is the user's responsibility to read and follow all instructions.
- UPON RECEIPT, IMMEDIATELY confirm that ALL pieces are included with the Portable Pro Lift Ramps set. Consult this guide for a list of all pieces.
- Check that the ramps have not become damaged during loading or shipping. If there are any concerns, call (800) 213-5883.
- No alterations shall be made to these ramps. These ramps CANNOT be cut down, shaved, or modified in any way.
- Keep these instructions with the product at all times and review before each use.
- It is the responsibility of this product's owner to furnish the instructions to any person that borrows or purchases the product.
- Inspect the product before use to ensure it is assembled properly and all parts are in safe working order and free of defects.
- All circumstances cannot be addressed in these instructions. Please use common sense and practice general safety measurements when using this product.
- Parts and/or instructions are subject to change without notice.

Safety

- Before using the ramps ensure other persons are clear of the vehicle and the ramps.
- Ensure that the ramps are free from damage before use.
- Do not exceed the rated vehicle weight capacity of 6,000 lbs.
- Do not use with tires that exceed 12-inches in width.
- Only use on dry, level, hard surfaces. Do not use if tires are wet.
- Position the ramps in line with the wheels, with the steering wheel pointed straight and the incline against the tire tread.
- Drive slowly and cautiously onto and off of the ramps. Never accelerate or brake suddenly.
- Another person, standing clear of the vehicle, should observe and guide the driver when using the ramps.
- Place the vehicle transmission in Park, or the lowest gear for manual transmissions, and engage the parking brake.
- Even on a level surface, it is advised to properly place wheel chocks to prevent the vehicle from rolling.
- With the wheels chocked, the Portable Pro Lift Ramps may offer a convenient way to complete transmission and drive train work. With an 8-inch vehicle elevation, access around and underneath the vehicle is greatly improved.

Overview

Refer to the guide below to ensure that your set arrived with all of the pieces.



Your Portable Pro Lift Ramp includes:

- 2 x INCLINE
- 2 x BLOCK
- 2 x BRIDGE
- 2 x FRONT BLOCK

If any pieces are missing or damaged in your shipment, notify us immediately at 800-213-5883.

Operations

1. Inspect the ramps to make sure they are not damaged. Make sure your vehicle is compatible with the ramps.
2. Position the ramps straight in line with the front and rear tires. Use a tape measure to ensure they are spaced equidistant from each other the entire length. Use all pieces as described in this guide.
3. With the steering wheel pointed straight and the incline against the tire tread, stay in the center of the ramps and carefully ascend the ramps in a slow and controlled manner until the tires rest on the flat, Portable Pro Lift Ramp blocks. Another person, standing clear and to the side of the vehicle, should guide the driver. Never accelerate or brake suddenly.
4. Upon the vehicle tires resting safely on the Portable Pro Lift Ramp blocks, shut-off the engine. Place the vehicle transmission in Park, or the lowest gear for manual transmissions, and engage the parking brake. Exit the vehicle and securely chock the tires.
5. Inspect the perimeter of the vehicle to ensure the vehicle is secure and stable prior to engaging in any further activity.
6. You may also remove various sections (incline, bridge) of the ramp once the car is fully secured on top of the Portable Pro Lift Ramp blocks. Remember to properly interlock the removed sections prior to descending the ramps.
7. In preparation for descending the ramps, verify the parking brake is engaged prior to the removal of wheel chocks.
8. Enter the vehicle, apply the brake and start the engine. Upon verifying the vehicle brake is engaged, disengage the parking brake.
9. Place the transmission in the appropriate position and slowly descend the ramps in a controlled manner. Another person, standing clear and to the side of the vehicle, should guide the driver.

Tips for Ascending or Descending Ramps

For both manual and automatic transmission vehicles equipped with a hand brake, the vehicle operator may cover the brake with the opposite foot, gradually applying and releasing for improved control of the vehicle. For both manual and automatic transmissions vehicles equipped with a hand brake, apply and release the hand brake to improve control of the vehicle.



Product Warranty and Liability

Race Ramps purchased from an authorized dealer or directly from Race Ramps LLC are backed by a one-year warranty. Our warranty is strictly limited to the repair or replacement of manufacturer defects and does not cover damage to a car, personal injury, labor, or any other damage or injury. Race Ramps LLC is not responsible for the damage caused by improper or unintended use. In no event shall Race Ramps LLC be responsible for consequential damage or costs. The warranty shall terminate one year from the date of purchase by the original owner and is not transferable. Because we are continuously conducting research and development, specifications are subject to change without notice. Those items sold by Race Ramps LLC, but manufactured by other companies are subject to the manufacturer's warranty and policy.

Questions? Please contact Race Ramps at 800-213-5883 or email support@raceramps.com.