

## General Guidelines

- It is the user's responsibility to read and follow all instructions.
- Keep these instructions with the product at all times and review before each use.
- It is the responsibility of this product's owner to furnish the instructions to any person that borrows or purchases the product.
- Inspect the product before use to ensure it is assembled properly and all parts are in safe working order and free of defects.
- Never modify this product in any way.
- All circumstances cannot be addressed in these instructions. Please use common sense and practice general safety measurements when using this product.
- Parts and/or instructions are subject to change without notice.



## Safety

- Before using the show cribs ensure other persons are clear of the vehicle and the cribs.
- Ensure that the show cribs are free from damage before use.
- Do not exceed the rated weight capacity of 3,000 lbs maximum axle capacity.
- Do not use with tires that exceed the width of the show crib.
- Only use on dry, level, hard surfaces. Do not use if tires are wet.
- Another person, standing clear of the vehicle, should provide visual assistance when elevating or lowering the car.
- Do not disconnect brakes or remove wheels and tires when the car is on show cribs.
- Always chock tires that are in contact with the ground upon the vehicle being positioned on the show cribs.
- Place the vehicle transmission in Park, or the lowest gear for manual transmissions, and engage the parking brake.



## Operations

1. Inspect the show cribs to make sure they are not damaged.
2. Park the vehicle on level ground. Place the vehicle transmission in Park, or the lowest gear for manual transmissions, and engage the parking brake.
3. If you are elevating the front of your car, place wheel chocks behind the rear tires. If you are elevating the rear of your car, place wheel chocks in front of the front tires.
4. Use approved vehicle lift equipment to carefully elevate the car high enough in order to place the show crib under the tire. Another person, standing clear of the vehicle, should provide visual assistance during this process.  
**Note:** Refer to the owner's manual accompanying the vehicle lift equipment for proper usage.
5. The show crib should be placed in a position where the car's tire rests evenly in the cradle.
6. When the show crib is placed in position, carefully lower the car until the tire rests in the show crib. Repeat steps 4-5 as needed.
7. Inspect the perimeter of the vehicle to ensure the vehicle is secure and stable prior to engaging in any further activity.
8. In preparation for removing the car off the show cribs, verify the parking brake is engaged.
9. When removing the car off the show cribs, carefully elevate the car high enough in order to remove the show crib. NEVER DRIVE OFF OF THE SHOW CRIBS.
10. Keep in mind to chock your tires after they make contact with the ground again.

## Product Warranty and Liability

Race Ramps purchased from an authorized dealer or directly from Race Ramps LLC are backed by a one-year warranty. Our warranty is strictly limited to the repair or replacement of manufacturer defects and does not cover damage to a car, personal injury, labor, or any other damage or injury. Race Ramps LLC is not responsible for the damage caused by improper or unintended use. In no event shall Race Ramps LLC be responsible for consequential damage or costs. The warranty shall terminate one year from the date of purchase by the original owner and is not transferable. Because we are continuously conducting research and development, specifications are subject to change without notice. Those items sold by Race Ramps LLC, but manufactured by other companies are subject to the manufacturer's warranty and policy.

**Questions?** Please contact Race Ramps at 800-213-5883 or email [support@racerampramps.com](mailto:support@racerampramps.com).